

Moog

Subsequent 37



1. DOWNLOAD THE EDITOR

Use Moog's free Subsequent 37 Editor. Register your synth with Moog to get the link by email, or pick **Subsequent 37 Editor** on the page below. Skip the CV Editor (Subsequent 37 CV only).

[Moog Editor Download Links](#)

2. CONNECT & BACK UP

Connect your Subsequent 37 by USB and open the Editor. On the **SETUP** page, set MIDI Input and Output to your synth. Click **LIBRARIAN**, then **GET** to pull in your synth's presets, then **EXPORT BANK** to back them up. Each takes about three minutes.

3. LOAD YOUR PRESETS

In **LIBRARIAN**, right-click the **User** folder and choose **Reveal in Finder** (Mac) or **Open Folder Location** (Windows). Copy your presets folder into it, then reopen the Editor. Click the new folder and drag each preset onto a **HARDWARE PRESETS** slot you do not use, since it replaces that slot. With **AUTO SEND** off, names stay in italics until you click **SEND**.

4. TEST OUT YOUR NEW PRESETS

You are good to go! Play through the sounds and see what inspires you. Don't forget to tag the artist on social media if you share something. They would love to hear how you are using their presets.

Troubleshooting Tips

[Moog Troubleshooting](#)

[Subsequent 37 Manual](#)

Made for the Subsequent 37, not the Subsequent 25 or Sub Phatty.

Editor won't connect? Back up with the synth's **ALL PRESETS** SysEx dump into a SysEx app Moog recommends, then send each file and save it with the manual's full **SAVE** steps (hold **SAVE** for one second to confirm).

[SysEx Librarian \(Mac\)](#)

[Bome SendSX \(Windows\)](#)

Still stuck? Reach out to us at support@soundshop.co. We would love to help!

