

IK Multimedia

TONEX ONE



1. GET TONEX AND TONEX EDITOR

TONEX Editor is IK's free app for loading your TONEX ONE. Download the free IK Product Manager, log in, choose **Register Product** and enter your TONEX ONE's serial number. Install TONEX from the Product Manager, ticking **TONEX Editor**. Update firmware from the Editor's **Setup** menu.

[IK Product Manager](#)

2. CONNECT AND BACK UP

Connect the TONEX ONE's USB C port to your computer (USB also powers it). Open TONEX Editor and pick your TONEX ONE from the top right menu. Click the **gear icon** and choose **Export Library** to save your presets as one .txl file. **Import Library** restores it.

3. LOAD YOUR PRESETS

Unzip your download and skip any __MACOSX folder or files starting with .__ (Mac leftovers). Drag the .txp files from the Presets folder into the **TONEX** app's preset browser. In TONEX Editor, click **Librarian** and drag each new preset from the software library (right) onto one of the 20 slots in the hardware library (left). That slot's preset is replaced, so pick one you do not need.

4. PICK THEM ON THE PEDAL AND PLAY

The footswitch plays 3 active slots: presets A and B in dual mode and 1 in stomp mode. Press **ALT** and the footswitch together (purple light). Use the footswitch to choose a slot, turn **BASS**, **MID** or **TREBLE** to pick a preset, then press **ALT** and the footswitch to confirm. You are good to go! If you share a clip, tag the artist.

Troubleshooting Tips

You can also drag a preset onto one of the 3 active slots in TONEX Editor's **Editor** tab.

[IK Multimedia Support](#)

[TONEX ONE Manuals](#)

Still stuck? Reach out to us at support@soundshop.co. We would love to help!

